PIN PROBLEMS

If you enter a wrong PIN:



Then the token switches off:



Wait 3 seconds before trying again. The token will display WAIT if you retry before 3 seconds.

After 9 wrong PINs:



After 10 wrong PINs:







DO NOT TRY ANYTHING ELSE!

IF YOUR TOKEN IS LOCKED. OR IF YOUR LOGIN ATTEMPTS ARE REJECTED

Call your Computer Representative, or the ECMWF Call Desk on +44 118 9499303

UNLOCKING YOUR PIN

Call your Computer Representative. or the ECMWF Call Desk on +44 118 9499303

Give your name and User ID, explain that your Actividentity token is locked.

You will be asked to give

a "challenge code":











Give the displayed challenge code to e.g. 45152390 your Administrator:

Your administrator will give you a challenge response over the phone for instance: 34756850



34756850





After 3 seconds. you will be asked to choose a new PIN.



Please refer to the section "TO CHANGE YOUR PIN" to complete this procedure.





Your Actividentity Keychain Token **V2**

A Quick User's Guide

Version: 2 May 2007

ON FIRST USE

Change the default PIN to your own. The default PIN is 1254 unless your Administrator gave you another one.



2 Enter the default PIN 1254



Choose a 4 to 6 digit PIN.

Simple PINs like 1234 or 0000 and the previous PIN 1254 are not accepted.



Now confirm your PIN:



After 3 seconds,
the token displays your first 8 digit
"one time password" (OTP).

NORMAL LOGIN



2 Enter your PIN:



3



The token immediately displays your 8 digit "one time password" (OTP).

The token will switch off after 60 seconds.

If you need another OTP, start this procedure all over again.

TO CORRECT A WRONG ENTRY

Use the key to backspace one digit.

TO CHANGE YOUR PIN





The token displays a "one time password"





Enter your new PIN (4 to 6 digits).

Simple PINs like 1234 or 0000 and

the previous PIN are not accepted.







Token switches off: